



















5KS29811

ASSEMBLY INSTRUCTIONS/INSTRUCTION D'ASSEMBLAGE/INSTRUCCIONES DE INSTALACIÓN

<b>A*1</b> 	<b>F*2</b>  M6×35MM	<b>①</b>  	<b>②</b> 	<b>③</b> 
<b>B*1</b> 	<b>G*6</b>  50MM	<b>④</b> 	<b>⑤</b> 	<b>⑥</b> 
<b>C*1</b> 	<b>H*6</b>  M6×50MM	<b>D*1</b> 	<b>I*3</b> 	
<b>E*2</b> 	<b>J*6</b> 	<b>K*1</b>  M6		